

- 1) BEGIN WITH PLACING THE SKID SEAT IN THE DESIRED POSITION.
  2) REMOVE REFLECTIVE TAPE AND CLEAN THE ENTIRE AREA WHERE THE SKID SEAT IS LOCATED. A RIGHT ANGLE GRINDER WITH A LIGHT SANDING WHEEL IS RECOMMENDED FOR SURFACE PREPARATION.
- 3) TACK THE SKID SEAT TO THE TRAILER IN THE POSITIONS LABELED "1". (THIS KEEPS THE SKID SEAT SECURE WHILE WELDING.)
  4) START WITH WELDING THE UNDERSIDE OF THE SKID SEAT. EVENLY SPACE STITCH WELDS THAT ARE 4"-5" LONG.
  5) FINISH WELDING THE TOP AND SIDES WITH A CONTINUOUS WELD.

- 6) ADD A SPACER BEHIND THE REAR BUMPERS IF NEEDED. TO PREVENT DAMAGE, THE BUMPERS MUST EXTEND PAST THE END OF THE SKID SEAT.